



Power Flame Burner Information

	Burner I	<u>Model</u>	<u>Motor</u>			Firing Sequence [1]		Standard UL Flame Safeguard			Gas Train		
Boiler Size	Gas and Gas/#2 Oil	#2 Oil	<u>Hors</u> Gas	epower #2 Oil and Gas/#2 Oil	Voltage	Gas	#2 Oil and Gas/#2 Oil	Gas	#2 Oil	Gas/#2 Oil	Size [4] [5]	Min. Pres.	Max. Pres.
C-20	C1-*-10	C1-O	1/3	1/2	115/60/1	On-Off	On-Off	RM7897A/UV	R7184P/CC	RM7897C/UV	1	3.5" w.c.	14.0" w.c.
C-30	C1-*-12	C1-O	1/2	1/2	115/60/1	On-Off	On-Off	RM7897A/UV	R7184P/CC	RM7897C/UV	11/4	5.5" w.c.	14.0" w.c.
C-40	C2-*-15	C2-OA	1/2	3/4	230/60/1 ^[3]	On-Off	L-H-O	RM7897A/UV	R7184P/CC	RM7897C/UV	11/4	4.5" w.c.	14.0" w.c.
C-50	C2-*-20A	C2-OA	3/4	3/4 / 1 ^[2]	230/60/1	L-H-O	L-H-O	RM7897A/UV	R7184P/CC	RM7897C/UV	11/2 / 11/4	6.8" w.c.	14.0" w.c.
C-60	C2-*-20B	C2-OB	1	11/2	230/60/1	L-H-O	L-H-O	RM7897A/UV	R7184P/CC	RM7897C/UV	2 / 11/2	5.2" w.c.	14.0" w.c.
C-70	C2-*-20B	C2-OB	1	11/2	230/60/1	L-H-O	L-H-O	RM7897C/UV	R7184P/CC	RM7897C/UV	2 / 11/2	6.7" w.c.	14.0" w.c.
C-80	C3-*-20	C3-O	11/2	2	208/460/3	L-H-O	L-H-O	RM7897C/UV	RM7897C/UV	RM7897C/UV	2 / 11/2	8.0" w.c.	14.0" w.c.
C-90	C3-*-20	C3-O	11/2	2	208/460/3	L-H-O	L-H-O	RM7897C/UV	RM7897C/UV	RM7897C/UV	2	7.9" w.c.	14.0" w.c.
C-100	C3-*-25B	C3-OB	3	3	208/460/3	L-H-O	L-H-O	RM7897C/UV	RM7897C/UV	RM7897C/UV	2	7.4" w.c.	14.0" w.c.
C-125	C4-*-30	C4-OB	5	5	208/460/3	L-H-O	L-H-O	RM7897C/UV	RM7897C/UV	RM7897C/UV	2	10.5" w.c.	14.0" w.c.
C-150	C5-*-30	C5-O	7 1/2	7 1/2	208/460/3	MOD	MOD	RM7840L/UV	RM7840L/UV	RM7840L/UV	2 1/2	10.0" w.c.	28.0" w.c.
C-175	C5-*-30	C5-O	7 1/2	7 1/2	208/460/3	MOD	MOD	RM7840L/UV	RM7840L/UV	RM7840L/UV	3	10.9" w.c.	28.0" w.c.
C-200	C6-*-30	C6-O	10	10	208/460/3	MOD	MOD	RM7840L/UV	RM7840L/UV	RM7840L/UV	3	11.5" w.c.	28.0" w.c.

^[1] Explanation of Firing Sequences:

Gas and Gas Sequence on Combination Gas/Oil Boilers

On-Off Slow opening gas valve, fixed air damper, diaphragm gas valve.

L-H-O Slow opening gas valve, adjustable position (LFS) air damper, linked to motorized gas valve.

Oil and Oil Sequence on Combination Gas/Oil Boilers

On-Off Fixed air damper, oil valve.

On-Off LFS Fixed air low fire start.

L-H-O Adjustable air damper (spring close), linked to oil pressure cylinder, oil pressure regulator and by-pass valve for LFS.

- [2] Oil blower motor is 3/4 hp and combination gas/oil is 1 hp.
- [3] Voltage on gas burner model is 115/60/1.
- [4] Model C-50 & C-60 Dual size gas trains: Leak test cock and main gas valve are indicated by the first number; combination gas valve/regulator and main shutoff cock are indicated by the second number.
- [5] Models C-70 & C-80 Dual size gas trains: Leak test cock, main gas valve and auxiliary gas valve are indicated by the first number; gas regulator and main shutoff cock are indicated by the second number.





Power Flame Burner Equipment

Equipment	Fuel	Description					
Control Cabinet	Gas, #2 Oil, Gas/#2 Oil	NEMA 1A with hinged door.					
Control Voltage Transformer	Gas, #2 Oil, Gas/#2 Oil	Included with all but 115/60/1 burners.					
Motor Starter	Gas, #2 Oil, Gas/#2 Oil	Contactor on all single phase motors. Magnetic starter with overload protection on 3-phase motors.					
Fusing	Gas, #2 Oil, Gas/#2 Oil	Control circuit only.					
Ignition	Gas and Gas/#2 Oil	Gas/Electric pilot.					
	#2 Oil	Direct spark.					
0:		Two [power on and fuel on].					
Signal Lights	Full Mod	Four [power on, fuel on, flame failure, and call for heat]					
A: E! 0 () 0 !! !	0, 0, 0	All models.					
Air Flow Safety Switch	#2 Oil	C-70 and larger					
Gas Train	Gas and Gas/#2 Oil	UL gas train for minimum inlet pressure indicated on Burner Information table. Shipped unassembled and consisting of the following: Manual shut-off valve. Gas pressure regulator Manual leak test valve. Automatic gas valve: Diaphragm type with On-Off sequence. Solenoid type all others. Safety gas valve: Solenoid type. High and Low gas pressure switches: Models C-60 and larger.					
Oil Pump	#2 Oil and Gas/#2 Oil	Integral with burner.					
Pilot Gas Controls	Gas, #2 Oil, Gas/#2 Oil	All models with gas/electric pilot have manual pilot shut-off valve, soft seat low gas pressure regulator and solenoid gas valve.					
Fuel Changeover	Gas/#2 Oil	Manual switch.					